

# Remote Control Layout

## ADB Polaris Remote Control

### Power (TV)

Turn TV on or off

### REC

Begins recording

### LIST

For future use

### MENU

Displays Menu Bar

### Arrow Buttons

Move highlight in system screens

### GUIDE

Displays Guide

### VOL + / -

Adjust volume

### MUTE

Toggle audio on or off

### FAV

Toggles closed captions on or off

### "A"

Use when red button is requested on screen

### DAY - / DAY +

Jumps Guide 1 day ahead or back

### Number Pad

Enter a channel number or PIN

### SWAP

For future use

### Power (CBL)

Turn set top box on or off

### Playback Controls

Control playback of VOD and recordings

### LIVE

For Future Use

### INFO

Display the Infobar

### OK|SEL

Enter a choice you have made

### EXIT

Close any screen and return to TV

### CH +/-

Change the channel

### LAST

Return to previous channel

### "B"

Use when blue button is requested on screen

### PG + / -

Jump Guide 1 page up or down

### VOD

For future use

